


# LUXFETISH

## ELECTRO-SEX SHOCK BUTT PLUG

WITH REMOTE CONTROL

### OPERATING THE PRODUCT



### TO BEGIN:

1. Install 2 AAA batteries into the device.
2. Insert the electrode wire into the output outlet at the top of the controller.
3. Attach the metal onto the desired area of the body.
4. Press the ON/▲ button to power on the device.
5. After the device is powered on, press the ON/▲ button again to activate the device's functions at the lowest intensity speed.
6. Press the S/P button to select between speed and power. Ten levels of speed and power are available.
7. Use the ON/▲ and OFF/▼ buttons to increase or decrease the intensity of the speed or power.
8. Press the MODE button to select between automatic stimulation programs or manual programs.
9. Adjust the power/intensity to a comfortable level and enjoy the stimulation.
10. To power off the device, reduce the power intensity to level 1, and press OFF/▼ button.

**NOTICE:** Preferably, use the highest quality AAA batteries, and change the batteries when they are running low. Recommended for use for 15 minutes per session, 1 to 2 times per day.

**DANGER:** Do not use this unit if you are using an implanted electronic medical device such as a pacemaker or other life-preservation devices, or electronic medical devices that monitor health functions.

**WARNING:** If you have one of the following conditions, please consult with your physician before purchasing or using this device. If you have any doubt as to your health status, please consult your physician prior to use.

Acute disease; malignant tumor; infective disease; pregnancy; heart disease; high fever; abnormal blood pressure; lack of skin sensation or any abnormal skin conditions; any condition requiring the active supervision of a physician.

### NOTICE:

- Do not use this device while driving.
- Do not use this device while sleeping.
- Do not use this device in high humidity areas such as bathrooms.
- Keep this device out of reach of children.
- Stop using this device immediately if you feel pain, discomfort, dizziness or nausea.
- Do not attempt to move the electrode pads while the device is in operation.
- Do not use the device around the heart, on the head, mouth, pudendum or blemished skin areas.

### TROUBLESHOOTING:

Stimulation is weak or non-existent	Are the wires connected to the main device properly?	Ensure that the parts are connected.
	Are the batteries dead?	Replace the batteries with a fresh new set.
Skin turns red	Was your treatment time too long?	Stop treatment or treat another area.
Skin feels numb	Are shock butt plug dirty?	Clean with damp cloth.
	Do the shock butt plug touch the skin closely?	Remove it and place back onto the skin.
Device does not turn on	Are the batteries installed correctly?	Remove and re-install batteries.
	Are the batteries dead?	Replace the batteries with a fresh set.

### MODEL: LF5318

