

LUXFETISH


RECHARGEABLE THRUSTING COMPACT SEX MACHINE WITH REMOTE CONTROL

3 SPEEDS & 7 PATTERNS MOUNTABLE SUCTION BASE

OPERATING THE PRODUCT



HEATING FUNCTION
WARMS TO PROVIDE
A FEELING OF LIFELIKE
INTERNAL HEAT



**VIBRATION &
THRUSTING
FUNCTIONS**
ADDS STIMULATION
TO THE EXPERIENCE

TO BEGIN:

01. Charge the sex machine by plugging the USB cable into a USB charging point, and the electrical connector into the base of the sex machine.
02. The sex machine will take approximately 5 hours to fully charge, and will give you up to 60 minutes of play.
03. Your sex machine features one realistic dildo and one G-spot dildo. To attach a dildo, push the base of the dildo into the top of the machine and twist into place.
04. Press and hold the power button to turn the sex machine on.
05. Press the warming button to warm your dildo to around 105°F / 40°C.
06. Press the thrust button to turn on the thrusting function. Press repeatedly to explore the various thrusting patterns and speeds.
07. Press the vibration button to turn on the vibration function. Press repeatedly to explore the various vibration patterns and speeds.
08. Your sex machine can also be used with the remote control. The remote control will also need to be charged, using the same USB cable. It will take 120 minutes to fully charge, and give you up to 10 hours of play.
09. To use the remote control, first turn the sex machine on by pressing the power button. Then press your desired function button on the remote. Press the function button repeatedly to change the pattern or speed.
10. You can use the suction cup to attach your sex machine to a smooth surface, such as a table or headboard.
11. Use with water-based lubricant to enjoy your toy at its best.
12. After use, unscrew your dildo, clean with sex toy cleaner and leave to air dry until next time.

**REMOTE CONTROL RECHARGEABLE DILDO THRUSTING SEX MACHINE SET
MODEL: 81895**

